



FL3X Interface-PMC

www.flex-product.com

BENEFITS

- 4 bus connectors which can be flexibly equipped via pluggable transceivers
- Up to 8 bus channels with 1-2 bus channels on each bus connector
- Physical Layer available for CAN (-FD, -HS), FlexRay and 100BASE-T1
- Synchronous timestamp generation for all of the 8 channels (resolution 1 us)
- PMC-Adapter available for: PCI, PCIe
- Driver available for: Windows, Linux, Xenomai
- Numerous triggering capabilities
- Switchable on-board bus termination
- Trigger 2x in/out configurable
- Configurable bus termination
- Analyzing software FlexalyzerV2 included
- Bosch E-Ray IP core FlexRay controller
- Bosch D_CAN IP core CAN controller
- Bosch M_CAN IP core CAN-FD Controller
- MorethanIP 10/100/1000 Mbit/s Ethernet controller
- V2.1 A FlexRay protocol specification
- V2.0 A/B CAN protocol specification
- ISO 11898-1:2015 CAN protocol specification
- Bosch CAN-FD specification 1.0

FL3X INTERFACE-PMC – OVERVIEW

The FL3X Interface-PMC is a bus interface for automotive bus systems in PMC design. The card's 8 bus interfaces can be configured for different bus systems via Physical Layer (FL3X Tiny2) slots.

- PMC interface (PCI Mezzanine Card)
- FL3X Tiny2 exchangeable Physical Layer slots
- 4x M9 connector
- 3,3 V DC and 5 V DC compatible PCI power supply
- LEDs signal the state of the network

ETHERNET

- Synchronous hardware timestamps for all bus interfaces (CAN, FlexRay, Ethernet)
- Resolution of the timestamp 1 us (32-bit)
- FL3X Interface-PMC with Ethernet will be detected as standard Ethernet interface
- Access to the Ethernet packets by NDIS driver (raw sockets possible)
- Special WinPcap version allows access to the hardware timestamps of the Ethernet packets
- Access to the CAN and FlexRay packets by standard FlexCard API
- 100BASE-TX and 100BASE-T1 Physical Layer available
- External synchronization by trigger input possible

FLEXRAY

- Asynchronous monitoring mode allows listening without FlexRay synchronicity
- Combined asynchronous and synchronous monitoring mode (the procedure of a bus startup can be monitored and registered exactly)
- Configurable TX-acknowledges
- Network synchronicity will be reported immediately (with timestamp)
- Chronological correlation of bus messages with one timestamp base
- Firmware update directly at the user PC possible
- Extensive filter configuration available
- Significant bus error messages
- Triggering on the precise slot and cycle

CAN / CAN-FD

- Silent mode useable for listening without bus interference
- Transmit FIFO up to 512 messages
- Configurable TX-acknowledges
- Significant bus error messages

PC INTERFACES

- Native PMC (PCI Mezzanine Card) interface
- PCI adapter available
- PCIe adapter available

DRIVER

- Uniform FL3X API
(Same API for FL3X Interface-PMC, FL3X Device-PCIe and FL3X Device-PXIe)
- CPU load reduction through DMA
- Driver Windows 64-bit (Windows 10)
- Driver Xenomai 32 bit/ 64 bit (Xenomai 3)
- Driver Linux 64-bit (5.15)

ADDITIONAL MODULES

The FR/FR-Syncmodule is a special FPGA image, which allows the synchronization of two independent FlexRay networks. After the startup of the master network at slot 1, the slave network at slot 2 will be started with the defined time offset. When both networks are synchronized, the defined time offset will be held constant by a control algorithm.

- Allows the realization of synchronized FlexRay/FlexRay gateways
- All FL3X API functions can be used

PHYSICAL LAYER FL3X TINY2

You can use the following FL3X Tiny2 combinations with FL3X Interface-PMC.

| Slot 1 | Slot 2 | Slot 3 | Slot 4 |
|-----------------|-----------------|-------------|-------------|
| 2x CAN-HS | 2x CAN-HS | 2x CAN-HS | 2x CAN-HS |
| 2x CAN-FD | 2x CAN-FD | 2x CAN-FD | 2x CAN-FD |
| FlexRay A/B (*) | 2x CAN-HS | 2x CAN-HS | 2x CAN-HS |
| FlexRay A/B (*) | 2x CAN-FD | 2x CAN-FD | 2x CAN-FD |
| FlexRay A/B | FlexRay A/B | 2x CAN-HS | 2x CAN-HS |
| FlexRay A/B | FlexRay A/B | 2x CAN-FD | 2x CAN-FD |
| FlexRay A/B | FlexRay A/B | FlexRay A/B | 2x CAN-HS |
| FlexRay A/B | FlexRay A/B | FlexRay A/B | FlexRay A/B |
| 100BASE-TX | FlexRay A/B (*) | | 2x CAN-HS |
| 100BASE-TX | FlexRay A/B (*) | | 2x CAN-FD |
| 100BASE-T1 | FlexRay A/B (*) | | 2x CAN-HS |
| 100BASE-T1 | FlexRay A/B (*) | | 2x CAN-FD |

(*) SelfSync - Allows autonomous start of the bus without further sync nodes

ORDER INFORMATION FL3X INTERFACE-PMC

| Product | Description | Order number |
|--------------------|---|--------------|
| FL3X Interface-PMC | The FL3X Interface-PMC is a PMC bus interface card. | 3-V0550A01 |

ORDER INFORMATION ACCESSORY PARTS FL3X INTERFACE-PMC

| Product | Description | Order number |
|---|---|--------------|
| FL3X Tiny2 1*100BASE-T1 | Pluggable transceiver module with one 100BASE-T1 transceivers (BC-M89810A2AMLG, Broadcom) | 3-V0550I01 |
| FL3X Tiny2 1*100BASE-TX | Pluggable transceiver module with one 100BASE-TX transceivers (DP83640TVV, NSC) | 3-V0550E01 |
| FL3X Tiny2 2*FlexRay | Pluggable transceiver module with two FlexRay transceivers (TJA1080ATS, NXP) | 3-V0550M01 |
| FL3X Tiny2 2*CAN-FD | Pluggable transceiver module with two CAN-FD/HS transceivers (TJA1044GT, NXP) | 3-V0550H01 |
| BusCable 200 8M9m 9SUBDFUNIVERSAL | 1. End: 7-pole M9 male connector, type 712 2. End: 9-pole SubD female connector Length: approx. 2 m | 3-00342Z01 |
| BusCable 2Way 200 8M9m 9SUBDF CAN&FR | 1. End: 8-pole M9 male connector, type 712 2. End: 2 x 9-pole SubD female connector Length: approx. 2 m | 3-00341L02 |
| BusCable 200 8M9m 9SUBDF OABR | 1. End: 8-pole M9 male connector, type 712 2. End: 9-pole SubD female connector Length: approx. 2 m | 3-00342P01 |
| BusCable 100 8M9m 9SUBDF CAN&FR | 1. End: 8-pole M9 male connector, type 712 2. End: 9-pole SubD female connector Length: approx. 1 m | 3-00342J01 |
| BusCable 4Way 60 9SUBDF 9SUBDF | 1. End: 9-pole SubD female connector 2. End: 4 x 9-pole SubD female connector Length: approx. 0.6 m | 3-00342J01 |
| BusCable 2Way 200 8M9m 9SUBDF OABR | 1. End: 8-pole M9 male connector, type 712 2. End: 2 x 9-pole SubD female connector Length: approx. 2 m | 3-00342Q01 |
| PMC-to-PCI-Adapter | Adapter for using the FL3X Interface-PMC with PCI slots. | 10016463 |
| PMC-to-PCIe-Adapter | Adapter for using the FL3X Interface-PMC with PCIe slots. | 10016484 |